



Removable spray film 400 ml (V406)

This is a special paint from Ambro-Sol that temporarily changes the color of your surfaces. It protects and decorates leaving the original surface intact.

REMOVABLE SPRAY FILM - A special paint that temporarily changes the color of your surface. Suitable for all non-porous surfaces, it creates a removable film both decorative and protective with a soft touch effect. The painted surface, once removed, leaves the original surface intact. Suitable for cars, sports gear, furnishings and much more.

Technical Specifications:

Quantity	400 ml – Net Wt. 10.4 oz 295 g
Box / Case	6 Pieces
Aspect	Spray can, containing pressurized liquid
Chemical nature	Based on plasticized synthetic resins
Color	Various
Odor	Typical of solvent
Relative density	at 68°F 0.72 ÷ 0.78 g/ml
Flash point	< 0° C/ 32 °F extremely flammable
Writing under the can	Barcode, batch code, color
Pressure	4/6 bar
Viscosity Coppa Ford	from 30" to 45" t = 68°F
Dry resual inside the can	16 % ± 1
Return	2 m ² n.c.f.
Glossiness	from 5 to 70 Gloss (glossmeter angol 60°)
Thermic resistance	Up to 100 °C/ 212 °F
Conditions to Use	> 5 °C/ 41 °F < 80 %
Electric conductivity	Non conductive
Drying times (t = 68°F):	To the 10 minutes
	Fully dry in 2 hours (6 coatings)
Overcoating	With Acrylic paint (V400): It can lose some elasticity. It can be over coated with a different color of removable spray film.
Observations: It may suffer a partial elastomeric degradation due to UV rays overtime	
Patent child-proof safety cap	
Ring and token on top reference color	
Possibility to apply different kinds of nozzles to have different spray effects	



APPLICATION FIELDS

Suitable on all types of metals, plastics and glass (even painted). Spray on smooth surfaces to create a better peel-off result. Avoid porous surfaces (ex. concrete, stone, wood). The paint is normally resistant to car wash, but in some cases, it is possible that the film will lose adhesion. In this case, re-apply to the affected parts. If steam cleaning, keep as far away as possible.


HOW TO USE

- Vigorously shake the can for at least 1 minute, until you hear the inner marbles move freely. It is also suggested to occasionally shake the can during use.
 - Carefully clean the surface before the application.
 - Test in a hidden area to verify compatibility of the surface with the paint.
- Remove secure seal on the cap.



APPLICATION

- Apply 6 crossed layers (horizontal and vertical = 1 layer) each every 10 - 15 minutes.
- Spray from a distance of 8 – 12” inches.
- The application of the first layer will have less coverage but will help adhesion of the following layers.
- After use, it is recommended to spray for 2 - 3 seconds with the can upside down this will help prevent the dispenser from clogging.



REMOVAL

- Carefully penetrate/cut the film in one corner of your painted object.
- Peel back film to remove.

Removing is easier on smooth surfaces and applied with a good thickness (6 layers).

MODE OF STORAGE

Before using: Stock the product in a dry location above 40°F degrees and below 113°F. After use, keep containers closed. In the original package, the product can be conserved for 24 months.

After the first use: conserve in a fresh and dry location, away from hot conditions. Keep out of reach of children.

This information, even if reliable, must be considered only approximate. We are not responsible for the wrong use of the product, or the violation of any license. Before using, the users should verify the suitability of the product for its specific use.

BEFORE USE, CONSULT THE SAFETY DATA SHEET OF THE PRODUCT